

42TKS (50 Hz)

Direct Expansion Fan Coil
R- 410A Refrigerant
Sizes 018 thru 060



Product Data

FAN COIL TECHNOLOGY AT ITS FINEST

The 50Hz 42TKS fan coil has the proven technology of Carrier fan coil units with Puron® refrigerant for horizontal applications. The design features contoured condensate pans with rugged drain connections, ensuring that little water is left in the unit at the end of the cooling duty cycle. The lack of standing condensate and corrosion free pans improves IAQ and product life, features homeowners appreciate.

Standard features include grooved tubing and louvered fins. Coil circuiting has also been updated to make the most of all Carrier air conditioners. Units come with solid state fan controls, 6mm thick insulation, multi- speed motors, and fully-wettable coils.



TABLE OF CONTENTS

| | <u>Page</u> |
|--|-------------|
| FEATURES / BENEFITS..... | 2 |
| MODEL NUMBER NOMENCLATURE | 3 |
| TECHNICAL DATA..... | 4 |
| UNIT DIMENSIONS | 5 |
| ELECTRICAL DATA | 6 |
| COMBINATION MATRIX | 6 |
| WIRING DIAGRAM | 7 |
| FAN PERFORMANCE..... | 8 |
| OPTIONS AND ACCESSORIES | 9 |
| GUIDE SPECIFICATIONS | 9 |
| SAFETY CONSIDERATIONS..... | 11 |
| RECEIVING / INSTALLATION / STARTUP / SERVICE | 12-16 |
| CONTROLLER FOR DUCTED FAN COIL UNITS | 17-19 |
| TROUBLESHOOTING | 20 |
| START-UP CHECK LIST | 21-22 |


FEATURES / BENEFITS

- Every compact one-piece unit arrives fully assembled, tested, and ready to run.
- Designed especially for high ambient environment.
- The drain pan is polyester powder coated for extra protection.
- Flexibility to provide left hand and right-hand coil connections.
- Metallic Blower double inlet forward curved blades.
- 3 speed motor.
- Standard galvanized sheet metal casing.
- Low unit height suitable for low false ceiling application.
- Washable aluminum filter.
- 6mm thickness internal insulation with 50 kg/m³ density.
- Low noise level suitable for all application.
- Sweat connections for easy installation and maintenance.

Carrier's 42TKS direct expansion fan coils are designed to cover low to medium range of air flow requirements. They are compact and ready to fit in the under-ceiling application. All units come with solid-state fan controls, 6mm insulation, quiet multi-speed motors, and fully wet coils. 42TKS are designed for ease of service in under ceiling applications. A carton template for easy location of mounting hardware simplifies installation. Coils are made of aluminum fins mechanically bonded to copper tubes for superior heat transfer. Metallic blower double inlet forward curved blades attached to 3-speed high efficiency motors. Galvanized sheet metal casing protects against rust and drain pan is polyester powder coated for extra protection. The control board with the integrated thermostat control and washable Aluminum filters are standard feature. Piping connections position (Right Hand/Left Hand) is optional, and field interchangeable for various applications.

MODEL NUMBER NOMENCLATURE

MODEL: 42 TKS – R410A Series




TECHNICAL DATA

| 42TKS Unit Size | | 18 | 24 | 30 | 36 | 37 | 42 | 48 | 60 | |
|---|--|---|-----------|-----------|-----------|-----------|-----------|-----------|-----------|--|
| Unit Size | Tons | 1.5 | 2.0 | 2.5 | 3.0 | 3.0 | 3.5 | 4.0 | 5 | |
| Motor Rated Power | Watts | 80 | 125 | | 200 | | 250 | 300 | 500 | |
| Number of Motors / Speeds | 1 / 3 Speed | | | | | | | | | |
| Coil Material | Tube | Inner grooved Copper Tubes | | | | | | | | |
| | Fin | Aluminum Fins with Louvered profile | | | | | | | | |
| Coil Face Area | m ² | 0.2 | 0.25 | 0.3 | 0.43 | 0.43 | 0.43 | 0.43 | 0.5 | |
| Refrigerant Metering Device | Orifice | | | | | | | | | |
| Piston Size | | 46 | 57 | 57 | 68 | 68 | 68 | 78 | 90 | |
| Coil Connection Type | Soldered Connection | | | | | | | | | |
| Suction Connection Size | Inch | 5/8 | | 3/4 | | | 7/8 | | | |
| Liquid Connection Size | Inch | 3/8 | | | | | | | | |
| Drain Connection Size | Inch | 3/4 NPT / GI Steel, Externally Threaded | | | | | | | | |
| Blower | Metallic Blower with Double Inlet, Forward Curved Blades | | | | | | | | | |
| Filter Type | 1" Washable Aluminum Filter | | | | | | | | | |
| Filter Quantity | | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 | |
| Filter Size | mm | 675 x 215 | 900 x 215 | 550 x 215 | 550 x 315 | 550 x 315 | 550 x 315 | 550 x 315 | 650 x 315 | |
| Sound Pressure (H/M/L) @ ESP 0.2 in.wg at 1-meter | | 46/43/38 | 50/45/39 | 52/45/39 | 53/51/48 | 53/51/48 | 54/53/50 | 56/54/52 | 57/54/53 | |
| Unit Dimensions | | | | | | | | | | |
| Width | mm | 1040 | 1240 | 1440 | 1440 | 1440 | 1440 | 1440 | 1640 | |
| Depth | mm | 645 | | | | | | | | |
| Height | mm | 275 | | | 375 | | | | | |
| Net Weight | Kg | 29 | 33 | 38 | 55 | 55 | 57 | 58 | 68 | |
| Gross Weight | Kg | 32 | 36 | 42 | 60 | 60 | 62 | 63 | 73 | |

UNIT DIMENSIONS

Notes:

1. The piping connections drain pan outlet and control box are located on the right-hand side facing the airflow as factory standard. Left hand connection can be provided based on request.
2. Unit shall be installed for horizontal discharge. Suspend horizontally using the factory-provided holes located at the topside flanges of the unit.



| Unit Model | A | B | C | D | E | F | G | H | I | J | SUCTION LINE | LIQUID LINE |
|------------|------|------|------|------|------|------|------|-----|-----|-----|--------------|-------------|
| 42TKS018-7 | 733 | 713 | 803 | 842 | 834 | 872 | 1040 | 275 | 216 | 197 | 5/8" | 3/8" |
| 42TKS024-7 | 958 | 938 | 1028 | 1067 | 1059 | 1097 | 1240 | 275 | 216 | 197 | 5/8" | 3/8" |
| 42TKS030-7 | 1158 | 1138 | 1228 | 1267 | 1259 | 1297 | 1440 | 275 | 216 | 197 | 3/4" | 3/8" |
| 42TKS036-7 | 1158 | 1138 | 1228 | 1267 | 1259 | 1297 | 1440 | 375 | 316 | 297 | 3/4" | 3/8" |
| 42TKS037-7 | 1158 | 1138 | 1228 | 1267 | 1259 | 1297 | 1440 | 375 | 316 | 297 | 3/4" | 3/8" |
| 42TKS042-7 | 1158 | 1138 | 1228 | 1267 | 1259 | 1297 | 1440 | 375 | 316 | 297 | 7/8" | 3/8" |
| 42TKS048-7 | 1158 | 1138 | 1228 | 1267 | 1259 | 1297 | 1440 | 375 | 316 | 297 | 7/8" | 3/8" |
| 42TKS060-7 | 1358 | 1338 | 1428 | 1467 | 1459 | 1497 | 1640 | 375 | 316 | 297 | 7/8" | 3/8" |

Note: Provided suction & liquid line sizes are for unit connection only; refer outdoor unit IOM for field pipe sizes.

ELECTRICAL DATA

| Unit Model | Condenser Control Circuit | Power Supply | Voltage | | Fan | MCA | MOCP |
|------------|---------------------------|---------------|---------|-----|-----|-----|------|
| | | | Min | Max | FLA | | |
| 42TKS018-7 | 24V | 230V/1Ph/50Hz | 207 | 253 | 1.3 | 1.6 | 15 |
| 42TKS024-7 | | | | | 1.3 | 1.6 | 15 |
| 42TKS030-7 | | | | | 1.5 | 1.9 | 15 |
| 42TKS036-7 | | | | | 2.5 | 3.1 | 15 |
| 42TKS037-7 | | | | | 2.5 | 3.1 | 15 |
| 42TKS042-7 | | | | | 3.0 | 3.8 | 15 |
| 42TKS048-7 | | | | | 3.3 | 4.1 | 15 |
| 42TKS060-7 | | | | | 4.0 | 5.0 | 15 |

Legend

FLA — Full Load Amps

MCA — Minimum Circuit Amps


MOCP — Maximum Overcurrent Protection

COMBINATION MATRIX

| Outdoor Model | Indoor Model | Nominal Cooling Capacity (Btuh) | Nominal Cooling Capacity (TR) | Nominal Air Flow (CFM) |
|---------------|--------------|---------------------------------|-------------------------------|------------------------|
| Top Discharge | Fan Coil | | | |
| 38CKM018-X-7 | 42TKS018-7 | 18000 | 1.5 | 600 |
| 38CKM024-X-7 | 42TKS024-7 | 24000 | 2.0 | 815 |
| 38CKM030-X-7 | 42TKS030-7 | 30000 | 2.5 | 890 |
| 38CKM036-X-7 | 42TKS036-7 | 36000 | 3.0 | 1165 |
| 38CKM036-X-9 | 42TKS037-7 | 36000 | 3.0 | 1165 |
| 38CKM042-X-9 | 42TKS042-7 | 42000 | 3.5 | 1350 |
| 38CKM048-X-9 | 42TKS048-7 | 48000 | 4.0 | 1425 |
| 38CKM060-X-9 | 42TKS060-7 | 60000 | 5.0 | 1765 |

For detailed performance and matchup ratings please refer to corresponding outdoor product catalog.

WIRING DIAGRAM



LEGEND

FM : FAN MOTOR
 CAP : CAPACITOR
 SW : DIP SWITCH
 RM : ROOM SENSOR
 ID : INDOOR COIL SENSOR
 ITB : INDOOR UNIT TERMINAL BLOCK
 OTB : OUTDOOR UNIT TERMINAL BLOCK
 TR : TRANSFORMERS
 WIRE COLORS
 BR : BROWN RD : RED
 BL : BLUE WH : WHITE
 OR : ORANGE BK : BLACK
 YL : YELLOW

TERMINAL BLOCK LEGEND

Y1 & Y2 : OUTDOOR UNIT CONTROL - 24VAC
 G : GROUND CONNECTION
 L : LIVE CONNECTION
 N : NEUTRAL CONNECTION
 NOTE
 ----- FILED WIRING

DIP SWITCH SETTING

| DIP SWITCH | ON | OFF |
|------------|------|-----------|
| SW1 | COOL | OFF |
| SW2 | - | DX SYSTEM |

FAN PERFORMANCE

42TKS Air Flow (CFM) – English

| ESP - in.wg | 0.1 | | | 0.2 | | | 0.3 | | | 0.4 | | |
|-------------|------|------|------|------|------|------|------|------|------|------|------|------|
| Unit Model | H | M | L | H | M | L | H | M | L | H | M | L |
| 42TKS018-7 | 673 | 600 | 438 | 621 | 543 | 392 | 536 | 473 | 320 | 438 | 360 | 242 |
| 42TKS024-7 | 990 | 815 | 477 | 936 | 747 | 432 | 853 | 679 | 365 | 761 | 585 | 261 |
| 42TKS030-7 | 1039 | 929 | 706 | 990 | 890 | 674 | 927 | 833 | 646 | 853 | 767 | 582 |
| 42TKS036-7 | 1316 | 1180 | 842 | 1296 | 1165 | 753 | 1262 | 1132 | 702 | 1200 | 1076 | 644 |
| 42TKS037-7 | 1316 | 1180 | 842 | 1296 | 1165 | 753 | 1262 | 1132 | 702 | 1200 | 1076 | 644 |
| 42TKS042-7 | 1436 | 1370 | 977 | 1415 | 1350 | 876 | 1382 | 1316 | 816 | 1303 | 1237 | 740 |
| 42TKS048-7 | 1629 | 1474 | 1286 | 1534 | 1425 | 1203 | 1492 | 1386 | 1160 | 1420 | 1326 | 1116 |
| 42TKS060-7 | 1940 | 1854 | 1618 | 1853 | 1765 | 1488 | 1804 | 1712 | 1434 | 1711 | 1613 | 1357 |

42TKS Air Flow (L/S) – SI

| ESP - Pa | 25 | | | 50 | | | 75 | | | 100 | | |
|------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Unit Model | H | M | L | H | M | L | H | M | L | H | M | L |
| 42TKS018-7 | 318 | 283 | 207 | 293 | 256 | 185 | 253 | 223 | 151 | 207 | 170 | 114 |
| 42TKS024-7 | 467 | 385 | 225 | 442 | 353 | 204 | 403 | 320 | 172 | 359 | 276 | 123 |
| 42TKS030-7 | 490 | 438 | 333 | 467 | 420 | 318 | 437 | 393 | 305 | 403 | 362 | 275 |
| 42TKS036-7 | 621 | 557 | 397 | 612 | 550 | 355 | 596 | 534 | 331 | 566 | 508 | 304 |
| 42TKS037-7 | 621 | 557 | 397 | 612 | 550 | 355 | 596 | 534 | 331 | 566 | 508 | 304 |
| 42TKS042-7 | 678 | 647 | 461 | 668 | 637 | 413 | 652 | 621 | 385 | 615 | 584 | 349 |
| 42TKS048-7 | 769 | 696 | 607 | 724 | 673 | 568 | 704 | 654 | 547 | 670 | 626 | 527 |
| 42TKS060-7 | 916 | 875 | 764 | 875 | 833 | 702 | 851 | 808 | 677 | 808 | 761 | 640 |

Legend:

CFM — Cubic feet per minute

L/S — Liter per second

in.wg — Inches of water gauge

Pa — Pascals

ESP — External static pressure

H — High speed, **M** — Medium speed, **L** — Low speed,

OPTIONS AND ACCESSORIES

Connection Side Option

Standard coil connection and electric box position is Right Hand facing air flow direction while the optional position is Left Hand facing the air flow for both coil connection and electric box. Customers can order this option directly from the factory. Also, units are designed to be field exchangeable if needed in the field.

Control Board Wire Extension

Standard wire length for control board is 15m. Optional extensions are available to enlarge the wire up to 30 m. If extension is required, please contact your local Carrier dealer.

GUIDE SPECIFICATIONS

COOLING ONLY DX INDOOR UNIT

SIZE: 1.5 TR TO 5.0 TR

SYSTEM DESCRIPTION

The direct expansion indoor units are designed for under ceiling installation, electrically controlled cooling. Unit shall be horizontal installation.

QUALITY ASSURANCE

- a) Units are designed / manufactured in accordance with ISO 9001:2015 facilities, International Standard for Quality Systems.
- b) Units are designed to conform to ASHRAE safety standard.
- c) Units are rated in accordance with ISO 13253 testing standard at T1 and T3 conditions.
- d) Insulation and adhesives are conforming to NFPA 90A requirements for flame spread and smoke generation.
- e) Units are run tested before packing.

DELIVERY STORAGE AND HANDLING

- a) Unit shall be stored and handled per manufacturer's recommendations.
- b) Lifting by crane requires either shipping top panel or spreader bars.
- c) Unit shall be stored or positioned in the upright position.

PRODUCT


- a) The units are factory assembled single piece cooling units.
- b) Unit cabinet shall be constructed of galvanized steel.
- c) Standard ducted unit's inner sections are insulated with NBR Elastomeric closed cell foam insulation, 50kg/m³ density.
- d) Drain pan is polyester powder coated on both sides & insulated outside.
- e) The unit fan wheel shall be directly connected to the motor. The fan wheel shall be dynamically balanced with double inlet forward curved type blower wheel.
- f) All coils are with 9.52mm seamless copper tubes and aluminum fins. Coil fins are mechanically bonded to copper pipes.
- g) The coil connections are sweat type LH/RH exchangeable.
- h) The unit fan motors are with permanently lubricated sleeve bearing and 3 speeds. The motor shall have internal overload protection and B class insulation.
- i) Unit shall have a wired control board with a built-in thermostat to be installed in the air-conditioned area and it shall have the following Features:
 - i. Control Modes – Cool, Dry, Fan, Auto Cool and Sleep mode.
 - ii. Compressor protections – 3 minutes restart protection.
 - iii. Indoor coil anti-freeze protection.
 - iv. Failure monitoring for room sensor and indoor coil sensor.
 - v. Non-volatile memory – keep system settings.
 - vi. Programmable On/Off timer.
 - vii. Random Restart Time Delay – to minimize voltage dip during compressor first cut in cycle upon power up for multiple units' operation.
- j) All electric parts are easily accessible for service.

INSTALLATION & OPERATIONS INSTRUCTIONS

SAFETY CONSIDERATIONS

The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Children should be supervised not to play with the appliance.

Improper installation, adjustment, alteration, service, maintenance or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Consult a qualified installer; service agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing. Follow all the safety codes. Wear safety glasses and work gloves. Use quenching cloths for brazing operations and have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions attached to the unit. Consult local building codes for special requirements. In absence of local codes, it is recommended that the USA standard ANSI/NFPA 70, National Electrical Code (NEC), be followed.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, are alert to the potential for personal injury. Understand the signal words **DANGER, WARNING, CAUTION, and NOTE**. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies hazards which could result in personal injury or death. CAUTION is used to identify unsafe practices, which may result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

INSTALLATION SAFETY CONSIDERATIONS

After the unit has been received and when it is ready to be installed or reinstalled, it must be inspected for damage. If damage is detected upon receipt, immediately file a claim with the shipping company or repair. This machine must be installed in a location that is not accessible to the public and protected against access by non-authorized people. This machine must not be installed in an explosive atmosphere.

Do not remove the skid or the packaging until the unit is in its final position. The units can also be lifted with slings, using only the designated lifting points marked on the unit (labels on the chassis and a label with all unit handling instructions are attached to the unit). Use slings with the correct capacity, and always follow the lifting instructions on the certified drawings supplied for the unit.

Motors are permanently lubricated; use of any external lubricant (including WD40) is not allowed. For units without factory supplied control it is the full responsibility of the user to install proper controls matching the unit's design and capable to carry components current, control wiring should be strictly follow local/national electrical codes (i.e. using telephone wires or similar is prohibited). Safety is only guaranteed, if these instructions are carefully followed. If this is not the case, there is a risk of material deterioration and injuries to personnel.

WARRANTY

Warranty is based on the general terms and conditions of the manufacturer. Any modifications to the design and/or installation made without discussion with Carrier and without advance written agreement will result in the loss of the right to any warranty claims and any claim for injury to personnel as a result of these modifications.




WARNING - THE MANUFACTURER'S WARRANTY DOES NOT COVER ANY DAMAGE OR DEFECT TO THE AIR CONDITIONER CAUSED BY THE ATTACHMENT OR USE OF ANY COMPONENTS, ACCESSORIES, OR DEVICES (OTHER THAN THOSE AUTHORIZED BY THE MANUFACTURER) INTO, ONTO, OR IN CONJUNCTION WITH THE AIR CONDITIONER. YOU SHOULD BE AWARE THAT THE USE OF UNAUTHORIZED COMPONENTS, ACCESSORIES, OR DEVICES MAY ADVERSELY AFFECT THE OPERATION OF THE AIR CONDITIONER AND MAY ALSO ENDANGER LIFE AND PROPERTY. THE MANUFACTURER DISCLAIMS ANY RESPONSIBILITY FOR SUCH LOSS OR INJURY RESULTING FROM THE USE OF SUCH UNAUTHORIZED COMPONENTS, ACCESSORIES, OR DEVICES.

RECEIVING

42TKS fan coil units are shipped individually packed in carton boxes. When cartons are individually off loaded from the truck, do not roll, or throw, or drop the carton to avoid damage to the contents. Store boxes upright as the symbols on the boxes indicated. Do not stack units more than 8 units high for sizes 018-024 and 6 units high for sizes 030 - 060.

UNPACKING INSTRUCTIONS


1. Prepare unit for unpacking
2. Remove two (2) pieces, of plastic straps
3. Open carton flaps
4. Lift unit assembly carefully out of carton box



Unpacking Instructions

PACKING INSTRUCTIONS

1. Lift unit assembly and carefully place into the carton box.
2. Place the IOM
3. Close carton flaps and seal with tape along flap side, wrap with two (2) pieces of plastic straps around the box



Packing Instructions

INSPECTION

Check the shipment against shipping list, remove unit from the carton and take off protective covering. If the unit has been damaged, file claim with transportation company and notify Carrier immediately.

PROTECTION

Protect unit from damage caused by job site debris. Do not allow dust, debris and water to get into the unit. This will damage unit's component and unit's performance will be affected.

PRELIMINARY CHECK

Following is a checklist which should be checked before the installation is started. The installer should be familiar with each of the following requirements before the actual installation.

1. Space requirements and clearances.
2. Ceiling or mounting strength.
3. Piping connections.
4. Condensate drains connection.
5. Power supply and wiring.
6. Air duct connections.
7. The condensing unit model number is the recommended by the factory (as per "Combination Ratings and Matrix").

PREPARE JOBSITE FOR UNIT INSTALLATION

To save time and to reduce the possibility of costly errors, set up a complete sample installation in a typical room at jobsite. Check all critical dimensions such as pipe, wire, and duct connection requirements. Refer to job drawings and product dimension drawings as required. Instruct all trades in their part of the installation.

IDENTIFY AND PREPARE UNITS

Be sure power requirements match available power source. Refer to unit nameplate and wiring diagram.

1. Check all tags on unit to determine if shipping screws are to be removed. Remove screws as directed.
2. Rotate the fan wheel by hand to ensure that the fan is unrestricted and can rotate freely. Check for shipping damage and fan obstructions.

UNIT CONFIGURATION

The piping connections drain pan outlet and control box are located on the right side of the unit facing the airflow direction as factory standard as shown in the unit picture. Left hand side connection is a factory option. However, the connections side can be relocated at site.

RIGGING AND UNPACKING

Unit should not be removed from carton until reaching final location to avoid damage. Inspect unit for shipping damage and file claim with transportation company if necessary, check nameplate voltage against available power supply. For special installation, consult local building and electrical codes.


INSTALLATION

PLACING UNIT IN POSITION

1. Select the unit location. Allow adequate space for free air circulation, service clearances, piping and electrical connections, and any necessary ductwork.
2. Be sure that the ceiling can support the weight of the unit. See "Physical Data" for nominal unit weight.
3. Move unit into position. Ensure unit is level or pitched towards drain to ensure proper drainage and operation.
4. Mounting units to the ceiling - When unit is lifted, access to the mounting holes is on the top panel of the unit. Hanger rods, fasteners, and other required hardware must be field supplied.

PIPING CONNECTIONS

Qualified personnel in accordance with local and national codes must perform all piping connections. Refer to "Physical Data" for piping connections. NOTE: It is important to have a common understanding of which side of the unit is the right-hand side and which is the left-hand side. When facing the supply air outlet from the front of the unit (air blowing in your face), your right hand will be on the right side of the unit and your left hand will be on the left side of the unit. Use the condensing unit manufacturer's recommended line sizes and requirements; see "Combination Ratings and Matrix". **Suction line must be insulated for correct operation.** Use refrigerant-grade copper lines only. The unit is not applied as a heat pump.



Typical Wiring & Piping Connections

NOTES:

1. All piping must follow standard refrigerant piping techniques.
2. All wiring must comply with the applicable local and national electric codes.
3. Wiring and piping shown are general points-of-connection guides only not intended for a special installation.
4. Insulate condensate line if run above a conditioned space.
5. The control board kit is factory supplied; no thermostat required.
6. The wall mounted wired room controller could control all system functions without wireless remote control.
7. Standard wire length for the control board is 7.5 m. If extension is required, please consult Carrier.

TEST AND INSULATE

When all joints are complete, perform hydrostatic test for leaks. Vent all coils at this time. Check interior unit piping for signs of leakage from shipping damage or mishandling. If leaks are found, notify a Carrier representative before initiating any repairs. Release trapped air from system (refer to Final Preparations section).

ELECTRICAL CONNECTIONS

Refer to unit nameplate for required supply voltage, fan amperage and required circuit amp. Refer to unit wire diagram for unit and field wiring; see "Typical Wiring & Piping Connections", "Typical Wiring Schematic" and "Electrical Data". Make sure all electrical connections are in accordance with unit wiring diagram and all applicable codes. The fan motor(s) should never be controlled by any wiring or device other than the factory-supplied control board. All field wiring must be in accordance with governing codes and ordinances. Any modification of unit wiring without factory authorization will invalidate all factory warranties and nullify any agency listings.

- Select proper wall location to fix display pad
- Connect communication cable end to its location in the PCB as shown in the wiring diagram.

Follow local/national wiring regulations and code for all wiring to the unit, in absence of local codes use power supply wires sizes which are at least 1.25 times the unit's full load current and circuit breaker size 2 - 2.25 times the unit's full load current.

DUCT CONNECTIONS

Install all ductwork to and from unit in accordance with all applicable codes. Duct construction must allow unit to operate within duct external static pressure limits as shown on job submittals. Units designed to operate with ductwork may be damaged if operated without intended ductwork attached. Units provided with outside air should have some method of low-temperature protection to prevent freeze-up. Insulate ductwork as required. Use flexible connections to minimize duct-to-unit alignment problems and noise transmission where specified. Set unit markings for minimum clearance to combustible materials and first 3 ft of ductwork. Install ductwork, accessory grilles and plenums so that they do not restrict access to filter. Cut openings for supply-air and return-air grilles. Be careful not to cut wires, piping or structural supports.

Caution: Prevent dust and debris from settling in unit. If wall finish or color is to be spray applied, cover all openings to prevent spray from entering unit. Unit efficiency will be reduced.

FINAL PREPARATIONS

1. Turn off power to the unit (open unit electrical disconnect).
2. Install the wired control panel kit and perform any other final wiring as applicable, see the controller for ducted fan coil units' section.
3. Clean dirt, dust, and other construction debris from unit interior. Be sure to check fan wheel and housing.
4. Rotate fan wheel by hand to be sure it is free and does not rub housing. Check that wing nuts securing fan assembly to fan deck are tight.
5. Be sure drain line is properly and securely positioned and that the line is clear. Pour water into drain to check operation.

Important: Do not start-up or operate unit without filter. Be sure filter and unit interior are clean.

START-UP

42TKS unit is designed to operate in hot and humid conditions without condensation problem because of the rubber insulated drain pan. Refer to the "Mandatory Startup Checklist and Record" for startup procedure.

SERVICE

Warning: Failure to follow this caution may result in equipment damage. Motors are permanently lubricated; Please do not use any external lubricant.

CLEAN COIL

1. Be sure electrical service switch is open, locked, and tagged while working on unit.
2. Coil can be cleaned by removing filter and bottom panel and brush between coil fins with stiff wire brush. Follow-up by cleaning with vacuum cleaner. If coil is cleaned with air hose and nozzle, take care not to drive dirt and dust into other components.

CHECK DRAIN

Lock open and tag unit electrical service switch. Check drain pan drain line and trap at start of each cooling season. A standard type pipe cleaner for 3/4-in. ID pipe can be used to ensure that pipe is clear of obstruction so that condensate is carried away.

CLEAN FAN WHEEL

Lock open and tag unit electrical service switch. For access to fan assembly, remove supply air duct and bottom panel. Use a stiff brush or vacuum to remove dirt and debris from scroll. Wipe all fan surfaces with a damp cloth.

CLEAN OR REPLACE AIR FILTERS

Lock open and tag unit electrical service switch. At the start of each cooling season and after each month of operation (depending on operating conditions) replace throwaway filter or clean permanent filter.

THROWAWAY FILTER

Replace filter with a good quality filter of the size shown in "Physical Data". Do not attempt to clean and reuse disposable filters.

PERMANENT FILTER

1. Tap on solid surface to dislodge heavy particles.
2. Wash in hot water.
3. Set filter on end so that water drains out through slots in frame. Allow filter to dry thoroughly. See Fig.8 for filter access.

UNIT CONTROLLER

1.1 Functions:

- Modes: Cool, Dry and Fan.
- Fan Speed: High, Medium, Low.
- Sleep Mode, programmable On/Off timer.
- Compressor protections: Compressor 3-minute restart protection, Indoor coil anti-freeze, Room Sensor and indoor coil sensor failure monitoring.
- Random restart to minimize voltage dip during compressor first cut in cycle upon power up.

1.2 Hardware Setting: A 2-way DIP switch is used to configure:


| DIP Switch | ON | OFF |
|------------|------|-----------|
| SW1 | Cool | OFF |
| SW2 | - | DX system |

1.3 Error Code: The corresponding error code will be shown one after another, in-case if multiple faults.







| Error code | E1 | E2 | E4 |
|------------|-------------|--------------------|------------|
| Fault | Room Sensor | Indoor coil sensor | Compressor |






























1.4 Description:

1) LCD Screen



2) Key Function:

| | | | | | | |
|----------|---|---|---|---|--|---|
| Icon |  |  |  |  |  |  |
| Function | On / Off | Mode | Fan | Set | Down | Up |



- 3) **System On/Off:** Press  to turn on or off the unit.
- 4) **Mode:** Press  key to change operating mode as follow:
Cool Only Model: Cool – Dry – Fan
- 5) **Fan Speed:** Press  key to select: Auto – High – Medium – Low which is indicated as A-3-2-1 on fan speed digital setting. Fan key is invalid in Dry mode.
- 6) **Temperature Setting:** Press  or  key to adjust set temperature. Temperature setting is 20°C to 30°C or 68°F to 85°F. Temp keys are invalid in Fan mode. Press  and  key together to switch between Celsius to Fahrenheit setting.
- 7) **Sleep:** Hold on  key to toggle sleep mode setting. Sleep key is invalid in Fan or Dry mode. Sleep mode will automatically cancel after 8 hours.
- 8) **RTC:** Press  key to enter RTC setting. Press  or  key to adjust hour or minute. Press  key to select hour, minute or day of week. Press  key to confirm and exit.
- 9) **Timer On or Off:** Press  and  keys to enter timer setting. Press  key to change items as follow: day of week, timer on enable or disable, timer on hour, timer on minute, timer off enable or disable, timer off hour, timer off minute. (When hour or minute being selected, it will flash).
Press  or  key to adjust the time for timer on or off being selected. Press  key to confirm and exit. Press  key to exit and ignore setting. It will exit and ignore setting automatically 6 sec after last key press. If timer ON is programmed ON symbol lights on. If timer off is programmed OFF symbol lights on. If ON or OFF timer is available for current day of week, Timer symbol lights on.
- 10) **Cancel Timer:** Hold  key for 3 seconds to cancel all timer settings.
- 11) **Key Lock:** In main menu, hold on  and  key to lock or unlock the keys. In key lock mode only  key is invalid.
- 12) **Information Browsing:** Press   keys for 3 sec to browse the following temperature.
Press  or  key to browse the temperature. Press  key to exit.



| RTC Display Zone | Temperature Display Zone |
|------------------|--------------------------|
| A1 | Room Temperature |
| A2 | Indoor Coil Temperature |

13) Error Code Display: Should there be any system error, it will be shown on temperature display zone. If multiple faults happen at the same time, the corresponding error code will be shown one after another.

| Fault | Error Code |
|--------------------------|------------|
| Room sensor fault | E1 |
| Indoor coil sensor fault | E2 |
| Compressor fault | E4 |
| Communication fault | E15 |

14) Edit System Parameter: Press  and  key enter password menu. Key in password

“1111” by  or  key to change selected digit.

Press  key to select the password digit. Press  key to verify the password. If password entry is correct, RTC display area will show the submenu number.

Press  or  key to select the sub menu, press  or  key to adjust the value selected sub menu.

Press  key to confirm and exit. Press  key to exit and ignore setting.

| Submenu | Description | Range | Options |
|---------|--------------------------------|-------|---|
| A1 | Temp display | 1 ~ 2 | 1: Disable Room Temp Display 2: Enable Room Temp Display |
| A2 | Cool mode fan control function | 1 ~ 2 | 1: Compressor off; Fan On 2: Compressor off; Fan off |

TROUBLESHOOTING

| Symptom | Possible Causes | Remedy |
|--|--|---|
| Unit will not run | Power off or loose electrical connection | Check for correct voltage at contactor in condensing unit. |
| | Thermostat out of calibration-set too high | Reset. |
| | Defective contactor | Check for control voltage at contactor coil - replace if contacts are open. |
| | Blown fuses or Transformer defective | Replace fuses / Check wiring-replace transformer. |
| | High pressure control open (if provided) | Reset-also see high head pressure remedy-The high-pressure control opens at 650PSIG |
| Outdoor fan runs, compressor doesn't | Run or start capacitor defective | Replace |
| | Start relay defective | Replace |
| | Loose connection | Check for correct voltage at compressor check & tighten all connections |
| | Compressor stuck, grounded or opens motor winding. | Wait at least 2 hours for overload to reset. Open internal overload. If still open, replace the compressor. |
| | Low voltage condition | Add start kit components |
| Insufficient cooling | Improperly sized unit | Recalculate load |
| | Improper indoor airflow | Check, remove obstructions - clean filters if necessary |
| | Incorrect refrigerant charge | Charge per procedure attached to unit service panel |
| | Air, non-condensable or moisture in system | Recover refrigerant, evacuate & recharge, add filler drier. |
| Compressor short cycles | Incorrect voltage | At compressor terminals, voltage must be $\pm 10\%$ of nameplate marking when unit is operating. |
| | Defective overload protector | Replace, if external - check for correct voltage |
| | Refrigerant undercharge | Add refrigerant |
| Indoor unit sweats | Low indoor airflow | Increase speed of blower or reduce restriction -clean air filters. |
| | Improper indoor unit installation | Assure condensate is draining properly & that insulation is dry. |
| High head-Low vapor pressures | Restriction in liquid line, expansion device or filter drier | Remove or replace defective component. |
| High head-high or normal vapor pressure - Cooling mode | Dirty outdoor coil | Clean coil |
| | Refrigerant overcharge | Correct system charge |
| | Outdoor fan not running | Repair or replace. |
| | Air or non-condensable in system | Recover refrigerant, evacuate & recharge |
| High head - high or normal vapor pressure - Heating mode | Low air flow - indoor coil | Check filters - correct to speed |
| | Refrigerant overcharge | Check system charge |
| | Air or non-condensable in system | Recover refrigerant, evacuate & charge |
| | Dirty indoor coil | Check filter - clean coil |
| Low head-high vapor pressures | Defective Compressor valves | Replace compressor |
| Low vapor - cool compressor - iced indoor coil | Low indoor airflow | Increase speed. of blower or reduce restriction |
| | Moisture in system | clean air filter iced indoor coil |
| High vapor pressure | Excessive load | Recheck load calculation |
| | Defective compressor | Replace |
| Fluctuating head & vapor pressures | Air or non-condensable in system | Recover refrigerant, evacuate & recharge |
| Gurgle or pulsing noise at expansion | Air or non-condensable in system | Recover refrigerant, evacuate & recharge |

START-UP CHECK LIST

MANDATORY START-UP CHECK LIST AND RECORD

IMPORTANT!

This page is a mandatory checklist & record – the check to be executed and data to be recorded for future reference in case of failure.

A copy of this checklist data must be submitted to Carrier representative. Completion of this checklist is a must for any field claim, no field support will be provided for incomplete or blank checklists.

Preliminary Information

| | | | |
|------------------------|--|-----------------------|--|
| Outdoor Model Number | | Outdoor Serial Number | |
| Indoor Model Number | | Indoor Serial Number | |
| Startup Date | | Technician Name | |
| Customer Name/Address | | Project Name | |
| Additional Accessories | | | |

| Pre-Start-Up Checklist | Yes | No | NA |
|---|-----|----|----|
| Outdoor Unit | | | |
| Is there any shipping damage? | | | |
| If the unit is damaged, please specify where: | | | |
| Will this damage prevent the unit start-up? | | | |
| Check power supply to see if it matches the unit data plate? | | | |
| Has the ground wire been properly connected? | | | |
| Are the circuit protection matched with the unit size and installed properly? | | | |
| Are the power wire gauge matched with the unit size and installed properly? | | | |
| Piping | | | |
| Are both refrigerant lines flushed / cleaned, connected to service valve sets and properly tightened? | | | |
| Are all the service valves open and back seated? | | | |
| Is the Stem Valves Installed and snug? | | | |
| Have all the refrigerant connections and piping joints checked for leaks and vacuum test conducted to 500 microns? | | | |
| Indoor Fan Coil Unit Piping | | | |
| Check accurate device size is matched and installed in fan coil unit? (If Applicable) | | | |
| Are the refrigerant connections properly connected and have been checked for leakages? | | | |
| Is condensate line connected? | | | |
| Is the condensate line free from obstacle and drains freely? | | | |
| Controls | | | |
| Are control power lines connected to their control power terminal block? | | | |
| Are terminal snug in the housing? | | | |
| Are control power lines and control cables routed separately (Not in the same conduit and not in same multi-conductor cable)? | | | |
| Are control wires connected to the same circuit as associated refrigerant lines? | | | |
| Check to make sure the subbase mounting to wall is secure. (Don't apply excessive force to mounting screw) | | | |

| Fan System | | | |
|---|-----|---|----|
| Does fan rotate freely? | | | |
| Are air filters in place and clean? | | | |
| Indoor Power Supply | | | |
| Does the power supply match the fan coil unit data plate? | | | |
| Is ground wire connected? | | | |
| Start-Up Checklist | Yes | No | NA |
| Check Indoor Fan Operation Under Ceiling Fan Coil Units | | | |
| Select fan mode, then initiate test sequence. Does the fan motor start at low speed, then shift to medium then to high? | | | |
| Start System Operation at the Fan Coil Unit | | | |
| Select cooling mode and adjust set point, it must be below current room temperature then observe unit operation. | | | |
| Does compressor start (After Initial Time Delay) and Run? | | | |
| Does outdoor fan run properly? | | | |
| After at least 15 minutes of running time, record all the information below: | | | |
| Outdoor Unit | | Fan Coil Unit | |
| Unit Amps(L1/L2/L3) | | Indoor Entering Air DB (Dry Bulb) Temp | |
| Voltage (L1/L2/L3) | | Indoor Leaving Air DB (Dry Bulb) Temp | |
| Vapor Line Pressure | | Indoor Entering Air WB (Wet Bulb) Temp | |
| Vapor Line Temp | | Indoor Leaving Air WB (Wet Bulb) Temp | |
| Liquid Line Temp | | Technician Name, Signature and Date: | |
| Entering Outdoor Air Temp | | | |
| Leaving Outdoor Air Temp | | | |

Manufacturer reserves the right to change, at any time, specifications and designs without notice and without obligations.